



# DEGREASER KITCHEN

## EXTREMELY POWERFUL, CONCENTRATED KITCHEN DEGREASING SPRAY



### TECHNICAL SPECIFICATIONS

Colour:	Transparent
pH-value approx.:	10,5

### STORAGE CONDITIONS

Keep in a dark, cool place, in an upright position, during storage or transportation.

### PRODUCT DESCRIPTION

Degreaser Kitchen is an extremely powerful, concentrated degreasing spray for cleaning virtually all types of fatty surfaces in the kitchen.

### FIELD OF APPLICATION

Suitable for use in the kitchen on the hot plate, cooker and oven. Degreasing household equipment.

### PROPERTIES

- Extremely powerful and easily removes burnt-on fat
- Quickly removable
- Fresh smell

### PREPARATION

**Surface Requirements:** Do not use on perspex or painted or vulnerable surfaces.

### APPLICATION

#### Directions for use:

Rotate the spray head a quarter turn to ON. Spray undiluted onto the surface to be cleaned and allow it to work in for a few seconds. Rub in using a damp (dish)cloth or sponge. Rinse with hot water. Repeat this process if necessary. Rotate the spray head to OFF after use. Cleaning kitchen equipment: spray it onto a damp cloth, rub it over the surfaces to be cleaned (remember to remove the plug from the electricity socket) and then dry it off.

**Advice:** Use Stainless Steel Cleaner for a long-lasting, bright shine on stainless steel surfaces.

**Points of attention:** Before starting it is recommended to test the product on a small, unseen area.

Our advice is based on extensive research and practical experience. However, in view of the large variety of materials and the conditions under which our products are applied, we assume no responsibility for the results obtained and/or any damage caused by the use of the product. Nevertheless, our Service Department is always at your disposal for any advice needed.